


»Lunaphon« Battery-Exchange:



Make sure you have clean hands.

Carefully pull out the round rubber part at the front of the »Lunaphon«.

(This part protects the loudspeaker, in the middle is white perforated metal.)

Remember its exact position. When you've taken it off, the loudspeaker will show.

Loudspeaker and batteries are inside a white paper tube which you need to pull out of the »Lunaphon« carefully (you can pull on the loudspeaker or, if you need to, use a needle).

In the picture below you see loudspeaker and batteries taken out of the »Lunaphon«. The batteries have long cables to both sides.

When you have exchanged or removed the batteries, you need some patience putting everything back together: All goes in the tube, the tube carefully back into the »Lunaphon«. Then put on the rubber part. This must fit right into the hole, it is held by pressure.

When the »Lunaphon« will be put in storage, the batteries should be removed.
It takes 2 average 1.5 Volt, Size AA batteries.

